

MASTER THE "ROADIE WRAP"!

To ensure your Pedal Python unfurls tangle-free, take a few minutes and learn how to coil your cable bundle using the "Roadie Wrap" technique. Video instructions at www.pedalpython.com



1. Grab the installed Pedal Python™ and coil once clockwise into your left hand.



2. Grab the cord a little farther apart than your first coil.



3. Now, twist your left hand down and your right hand upward. The twisting motion should begin to form a coil.



4. Bring the right hand to the left hand but this time bring the right hand **BETWEEN** the 1st coil and the 2nd coil.

Repeat steps 1-4 until your Pedal Python™ is completely wrapped!

TIP: When an AC cable is bundled, some users prefer to cut out a section a few feet from the amp end to allow the AC cable to break out of the snake to reach an outlet that is not near the amplifier. Additional zip ties and end wraps can be purchased at pedalpython.com.